

**Gorilla-Lift® Cable & Quick Link  
Model # GLC1 & GLQ1**

**INSTRUCTIONS FOR ATTACHING NEW CABLE WITH QUICK LINK**

1. Cut the cable being replaced from the springs with a bolt cutter.
2. Install new cable using the Quick Link.
3. Securely attach and tighten the Quick Link to both inner and outer springs.